POOL 7/8/9' PRO 一体落袋款

IRONMAN



BILLIARDS INSTRUCTION MANUAL

臺球桌安裝說明書

請先整體看一遍說明書，再根據步驟安裝 PLEASE READ THE INSTRUCTION MANUAL THOROUGHLY FIRST AND THEN INSTALL ACCORDING TO THE STEPS!


RASSON

JUN.2025

www.rasson.cn

HARDWARE / 五金單

表1

PACKAGE 包裝	ITEM # 部件	SAMPLE 圖樣	DESCRIPTION 規格類型	QTY. 數量
LEG 桌腳	H1		HEX HEAD CROSS BOLT 3/8" X 2-3/8"(M10 x 60mm)	16
	H2		FLAT WASHER 3/8" I.D. x #28	16
	H3		HEX HEAD BOLT 3/8" X 3-5/32"(M10-16G x 80mm)	4
	H4		FLAT WASHER 3/8" I.D. x #28	4
	H5		NUT 3/8" I.D.	4
CABINET 大框	H6		FLAT HEAD SCREW-COLORED 10# X 2-5/32"(M5 x 55MM彩鋅)	12
	H7		HEX HEAD BOLT 3/8" X 3-1/8"(M10-16G x 80mm)	8
	H8		HEX HEAD BOLT 3/8" X 2-9/16"(M10-16G x 65mm)	4
	H9		FLAT WASHER 3/8" I.D. x #22	12
	H10		NUT 3/8" I.D.	12
RAIL/POCKET/FRAME/SLATE 扶手 / 球袋 / 圖板 / 石板	H11		HEX HEAD CROSS BOLT 5/16" X 11/16"(M8-18G x 17mm)	36
	H12		FLAT WASHER 5/16" I.D. x #20	36
	H13		HEX HEAD CROSS BOLT 1/4" X 1"(M6-20G x 17mm)	16
	H14		FLAT WASHER 1/4" I.D. x #18	16
	H15		HEX HEAD BOLT 3/8" X 2-9/16"(M10-16G x 65mm)	18
	H16		FLAT WASHER 3/8" I.D. x #28	36
	H17		SPRING LOCK WASHER 3/8" I.D.	18
	H18		WRENCH 腳盤調節扳手	1
	H19		METAL BRACKET 裙板角件	18










HARDWARE / 五金單

表2

PACKAGE 包裝	ITEM # 部件	SAMPLE 圖樣	DESCRIPTION 規格類型	QTY. 數量
	H20		FLAT HEAD SCREW 4# X 21/32"(M3 x 17mm 黑鋅)	6

PARTS LIST / 配件單

表1

PACKAGE 包裝	ITEM # 部件	SAMPLE 圖樣	DESCRIPTION 規格類型	QTY. 數量
LEG 桌腳	1		LEG 腳	4
CABINET/BEAM 大框	2		END LEG BEAM 短邊圍板	2
	3		SIDE LEG BEAM 長邊圍板	2
	4		MIDDLE BEAM 中間木擋	2
APRON 裙板	5		END APRON 端邊裙板	2
	6		SIDE APRON 長邊裙板	2
	7		METAL CORNER 裙板護角	4
TOP RAIL 扶手	8		TOP RAIL LEFT SIDE 左扶手	2
	9		TOP RAIL RIGHT SIDE 右扶手	2
	10		TOP RAIL END 端边扶手	2
POCKET 球袋	11		CORNER POCKET 五金角袋	4
	12		SIDE POCKET 五金中袋	2
	13		PLASTIC CORNER POCKET 塑膠角袋	4
	14		PLASTIC SIDE POCKET 塑膠中袋	2
SLATE 石板	15		SLATE (LEFT) 石板(左)	1
	16		SLATE (CENTER) 石板(中)	1
	17		SLATE (RIGHT) 石板(右)	1

PARTS LIST / 配件單

表2

PACKAGE 包裝	ITEM # 部件	SAMPLE 圖樣	DESCRIPTION 規格類型	QTY. 數量
	18		CLOTH 臺尼	1
	19		BRIDGE HOLDER 架杆鈎	2
	20		ACCESSORY HOOK 三角框挂鈎	1

FIG 1




FIG 2




FIG 3





FIG 4



*Turn the leg levelers with wrench to adjust the levelness of table cabinet.
使用扳手轉動腳底座內腳盤，調節下框水平。

FIG 5





FIG 6


***Level slate with 18 LevelBox adjusters.Tighten the nut after Leveling the slate.**
使用18個石板水平調整器調節水平，調整水平後，將緊固螺母上擰緊



***Level Gauge**
水平儀

***Tighten the nut**
緊固螺母

FIG 7



*Cut holes in cloth at rail both locations.
石板螺杆孔開洞






FIG 8





*Pre-attach the H7&H8 bolts,then tighten them after attaching the Corner Pocket 11 and Middle Pocket 12 to rails.

*請先將H7&H8螺杆與扶手預裝，待下一步安裝五金角袋11和五金中袋12插入扶手後再擰緊。

FIG 9






FIG 10



FINISH



RASSON



No.18th Floor, Weiyangyipin Building, Leying Plaza, Bali Lake New District, Jiujiang City, Jiangxi Province, China

kevina@rasson.cn

+86-792-898-6880





